



Part nº	Buttons nr.
ERT2 H-TD	2
ERT4 H-TD	4
ERT6 H-TD	6
ERT8 H-TD	8
ERET4 H-TD	4 + Emergency stop
ERET6 H-TD	6 + Emergency stop
ERET8 H-TD	8 + Emergency stop
ERET10 H-TD	10 + Emergency stop
ERET12 H-TD	12 + Emergency stop

***** Review attached PDF*****

The information gathered in this technical documentation (Catalogue) has an informative character and can be modified without previous notice. DICSA will not accept any type of responsibility resulting from an inappropriate use of the product, except the ones related to manufacturing defects.