


Joysticks with button and switch (fitting included)









Part nº	JOYSTICK
EE1B	1 botón para 1 bobina / 1 button for 1 coil
EE1D	1 interruptor balancín para 2 bobinas / 1 button (2 functions) for 2 coils

The information gathered in this technical documentation (Catalogue) has an informative character and can be modified without previous notice. DICSA will not accept any type of responsibility resulting from an inappropriate use of the product, except the ones related to manufacturing defects.