

# Oleodinamica Marchesini V0667/V400

## primary-pressure-compensated sequence valve

Manufacturer: Oleodinamica Marchesini  
Manufacturer part number / published order designation: V0667/V400  
Published model: V0667/V400

### About this compilation

Prepared by Hydmaster from selected manufacturer documentation. Original technical pages follow without cropped drawings, rewritten data or altered units. This cover and index are Hydmaster editorial material, not a manufacturer-issued exact-execution datasheet.

Coverage: selected pages relevant to the identified size and configuration. Other options or neighbouring models retained on an original page apply only where explicitly identified.

### Execution notes and conditions

Exact supplier type does not print range: no numeric selected spring range or preset inferred from suffix.

Actual full supplier row + primary exact size/range and CODE/V or CODE/PP legend; no generated combinations, presets or option-specific envelope/mass.

### Source-page index

Source page numbers below are physical pages of each complete original PDF. The original printed page labels and technical content remain unchanged. Compiled page numbers count this cover/index.


#### Source A: Oleodinamica Marchesini VSQAPP exact execution reference

| Original pages | Compiled pages | Relevant content                                                                                  |
|----------------|----------------|---------------------------------------------------------------------------------------------------|
| 1              | 2              | Original size row and actual spring/adjustment legend, hydraulic circuit and installation drawing |


VALVOLE DI SEQUENZA AD ANNULLAMENTO  
PRESSIONE PRIMARIA  
SEQUENCE VALVES WITH PRIMARY PRESSURE  
COMPENSATION



SCHEMA IDRAULICO  
HYDRAULIC DIAGRAM



SCHEMA DI MONTAGGIO  
APPLICATION CIRCUIT



**IMPIEGO:**  
Valvola utilizzata principalmente per far funzionare in sequenza due cilindri: al raggiungimento di un determinato valore di taratura, la valvola si apre e va ad alimentare un secondo attuatore. La valvola di ritegno permette il libero passaggio del flusso nella direzione opposta. E' insensibile alle contropressioni, pertanto consente di utilizzare la pressione impostata dall'impianto per azionare entrambi gli attuatori.

**MATERIALI E CARATTERISTICHE:**  
Corpo: acciaio zincato.  
Componenti interni: acciaio temprato termicamente e rettificato.  
Guarnizioni: BUNA N standard.  
Tenuta: a cono guidato. Trafilamento trascurabile.

**MONTAGGIO:**  
Collegare C al cilindro e V all'alimentazione.  
Per l'impiego con due attuatori seguire le indicazioni di montaggio illustrate nello schema.

**A RICHIESTA**  
• Molle per diversi campi di taratura (vedi tabelle)  
• Pressioni di taratura specifiche (CODICE/T 000 specificando il valore di taratura)


**USE AND OPERATION:**  
Sequence valve is used to feed 2 cylinders in sequence: it provides flow to the secondary circuit when a primary circuit function has reached the pressure setting. Reverse flow is free. The valve is not affected by the back pressures and therefore it allows the circuit pressure be used by both circuits.

**MATERIALS AND FEATURES:**  
Body: zinc-plated steel.  
Internal parts: hardened and ground steel.  
Seals: BUNA N standard.  
Leakage: Guided poppet - negligible leakage.

**APPLICATIONS:**  
Connect C to the cylinder and V to the supply.  
For the installation on two cylinders follow the mounting instructions shown in the application circuit.

**ON REQUEST**  
• different setting range (see the table)  
• other setting available (CODE/T000 please specify the desired setting)

Temperatura olio: 50 °C - Viscosità olio: 30 cSt  
Oil temperature: 50 °C - Oil viscosity: 30 cSt



REGOLAZIONE - ADJUSTEMENT

|                     |                                                            |
|---------------------|------------------------------------------------------------|
| CODICE/V • CODE/V   | Volantino • Handknob                                       |
| CODICE/PP • CODE/PP | Predisposizione alla piombatura • Arranged for sealing cap |
| CODICE/P • CODE/P   | Piombatura • Sealing cap                                   |

| CODICE<br>CODE | SIGLA<br>TYPE | C - V<br>GAS | L<br>mm | L1<br>mm | L2<br>mm | L3<br>mm | L4<br>mm | L5<br>mm | L6<br>mm | H<br>mm | S<br>mm | PESO/<br>WEIGHT<br>Kg |
|----------------|---------------|--------------|---------|----------|----------|----------|----------|----------|----------|---------|---------|-----------------------|
| V0642          | VSQAPP 3/8"   | G 3/8"       | 74      | 156      | 14       | 7        | 55       | 39       | 31       | 70      | 30      | 1,250                 |
| V0662          | VSQAPP 1/2"   | G 1/2"       | 80      | 162      | 15       | 7        | 55       | 37       | 33       | 70      | 30      | 1,280                 |
| V0667          | VSQAPP 3/4"   | G 3/4"       | 100     | 192      | 20       | 10       | 80       | 50       | 50       | 100     | 40      | 2,844                 |

MOLLE - SPRINGS (3/8" - 1/2")


| Campo di taratura<br>Setting range (bar) | Incremento bar per giro<br>Pressure increase (bar/turn)<br>Q= 4l/min | Taratura standard<br>Standard setting<br>(bar) |
|------------------------------------------|----------------------------------------------------------------------|------------------------------------------------|
| 10 - 50*                                 | 7                                                                    | 30                                             |
| 20 - 100                                 | 12                                                                   | 75                                             |
| 10 - 180 standard                        | 30                                                                   | 90                                             |
| 50 - 250                                 | 45                                                                   | 130                                            |
| 80 - 300                                 | 50                                                                   | 150                                            |

MOLLE - SPRINGS (3/4")

| Campo di taratura<br>Setting range (bar) | Incremento bar per giro<br>Pressure increase (bar/turn)<br>Q= 4l/min | Taratura standard<br>Standard setting<br>(bar) |
|------------------------------------------|----------------------------------------------------------------------|------------------------------------------------|
| 20 - 200                                 | 40                                                                   | 160                                            |
| 50 - 400 standard                        | 80                                                                   | 180                                            |

\*Per tarature inferiori a 70 Bar: Q = 12 l/min      \*For setting less than 70 Bar: Q = 12 l/min

PERDITE DI CARICO  
PRESSURE DROP CURVE



PRESSIONE/PORTATA  
PRESSURE/FLOW

