




Part nº	Stroke (mm)	ØH	A	B	C	D	E	F	G	I	J
MCSM12010	10	6	17	M6	16	10	75	16	130	M16*1,5	18,3
MCSM12025	25	6	17	M6	16	10	75	16	130	M16*1,5	18,3
MCSM12050	50	6	17	M6	16	10	75	16	130	M16*1,5	18,3

LC = Stroke
The spring is located in the small chamber